



SADDLEBAG TAILLIGHT ACCENTS 3209

FITS '06-UP GL1800 ONLY

PARTS INCLUDED

- 1 Left Upper Accent
- 1 Right Upper Accent
- 1 Left Lower Accent
- 1 Right Lower Accent
- 2 Alcohol Pad
- 1 Installation Instructions

Please read and understand entire instructions before starting installation.

THANK YOU FOR CHOOSING KÜRYAKYN!

ATTENTION! The adhesive may not correctly bond if applied at temperatures less than 50°F. Do not attempt this installation in temperatures less than 50°F.

PROCEDURE

STEP 1 Use a supplied alcohol pad to clean the taillight. Be sure to remove any grease, oil, dirt, or other debris that may prevent the adhesive from bonding.

ATTENTION! Be sure the area is free of grease, oil, dirt, or other debris to ensure proper adhesion. Kuryakyn **WILL NOT** warranty any parts lost due to improper installation.


STEP 2 Locate the left upper chrome accent in the installation kit.

ATTENTION! There is a distinct left and right for all accent pieces; to determine on which side the accent should be used, match the profile of the short, curved end of the accent piece to the profile on the light assembly. See PIC.1.

STEP 3 Rub the paper backing on the self-adhesive strips to activate the adhesive then peel the paper backing off the adhesive strip.

STEP 4 Position the accent piece on the light; the top of the accent should be 1/8" above the red and white separation on the lens. See PIC.2.

-cont.-



3209-11GL-1006

CUSTOMER SERVICE

877.370.3604 (toll free)

INSTALLATION QUESTIONS

techsupport@kuryakyn.com
or call 715.247.2983

LIMITED WARRANTY

Kuryakyn warrants that any Kuryakyn products sold hereunder, shall be free of defects in materials and workmanship for a period of one (1) year from the date of purchase by the consumer excepting the following provisions:

- Kuryakyn shall have no obligation in the event the customer is unable to provide a receipt showing the date the customer purchased the product(s).
- The product must be properly installed, maintained and operated under normal conditions.
- Kuryakyn makes no warranty, expressed or implied, with respect to any gold plated products.
- Kuryakyn shall not be liable for any consequential and incidental damages, including labor and paint, resulting from failure of a Kuryakyn product, failure to deliver, delay in delivery, delivery in nonconforming condition, or for any breach of contract or duty between Kuryakyn and a customer.
- Kuryakyn products are often intended for use in specific applications. Kuryakyn makes no warranty if a Kuryakyn product is used in applications other than intended.
- Kuryakyn electrical products are warranted for one (1) year from the date of purchase by the consumer. Components of Kuryakyn products containing L.E.D.s will be warranted for defects in materials and workmanship for 3 years from the date of purchase.
- Kuryakyn makes no warranty of any kind in regard to other manufacturer's products distributed by Kuryakyn. Kuryakyn will pass on all warranties made by the manufacturer and where possible, will expedite the claim on behalf of the customer, but ultimately, responsibility for disposition of the warranty claim lies with the manufacturer.

ABOUT OUR CATALOG

You'll find all our innovations for H-D, GL and Metric Cruisers in our annual catalogs. Order online today—select the "CATALOGS" icon. Each Kuryakyn product comes with a Proof-of-Purchase good for a complimentary catalog. Details in packaging.

Be sure to ask your local dealer about other Kuryakyn products, the motorcycle parts and accessories designed for riders by riders.

©2005 Kuryakyn USA All Rights reserved.



STEP 5 Press the accent firmly into place and hold for one minute to ensure proper adhesion. Full bond strength will occur within 24 hours.

STEP 6 Repeat for the opposite side.

STEP 7 Locate the left lower accent piece. Rub the paper backing on the self-adhesive strips to activate the adhesive then peel the paper backing off the adhesive strip.

STEP 8 Position the accent piece on the light; align the bottom of the accent piece with the seam between the light housing and the body trim. See [PIC.3](#).

STEP 9 Press the accent firmly into place and hold for one minute to ensure proper adhesion. Full bond strength will occur within 24 hours.

STEP 10 Repeat for the opposite side.

Ride On!

Kuryakyn

PIC.3



PAGE

2